





QUICK START GUIDE

Wireless Charger Qi2 3in1
with 1 x Wireless charger for Cell Phone
1 x Wireless charger on base for Earbud
1 x Watch charger
WCDQi201

How it works



- 1, Qi2 Wireless charging (foldable)
- 2, Watch charging (foldable)
- 3, Retractable Stand
- 4, LED light
- 5, Earbud charging base
- 6, USB-C port

How it works

Connecting:

1. Connecting the 3in1 docking
 - Please use USB-C cable connect the Charger.
 - Connect the USB-C of the supplied cable to the USB-C port on the 3in1 dock.
 - The status LEDs will turn on. (and will off in 2-3 seconds which shown product is function)



2. Charging devices with the 3in1 docking

A. Wireless charging

- Place your smartphone on the charging pad. The docking will initiate wireless charging and LED 1 will be blue.

Note: Charging pad is magnetic. Smartphones supporting magnetic charging will be magnetically attached to the 3in1 docking. For smartphones without magnetic charging, the metal ring which can be used to attach on the smartphone to achieve the magnetic function. Otherwise, the 3in1 docking can still be used to wireless charging the smartphones without magnetic function.

B. Charging watch with the docking

- Place your watch on the watch charging pad. The docking will initiate wireless charging and LED3 will be blue.

C. Charging earbud with the docking

- Place your earbud on the Earbud charging pad. The docking will initiate wireless charging and LED 2 will be blue.



Specifications

- Input USB-C PD3.0: 5 V ~ 3 A, 9 V ~ 3 A (27 W Max.)
 - Output: Magnetic Wireless charging: 5 W, 7.5 W, 10 W, 15 W Max.
Wireless Charging on base - 5 W.
Watch charging - 2.5 W. Total Output: 22.5 W
 - FOD protection
 - Over charge voltage protection.
 - Over Discharge Voltage protection
 - Over current protection.
 - Short circuit protection.
 - Over temperature protection.
 - Dimensions: 90.4 x 74.7 x 36mm
 - Weight: 195g
 - Material Flame Resistant PC + Zine Alloy
- Two year Limited warranty - for further details visit www.verbatim.com/warranty

Safety Instructions

- Protect the product from dirt, moisture and overheating and use it in dry rooms only.
- Do not drop the product and do not expose it to any major shocks.
- Do not operate the product outside the power limits given in the specifications.
- Use the product only for the intended purpose.
- As with all electrical products, this device should be kept out of the reach of children.
- Do not use the product in the immediate vicinity of heaters, other heat sources or in direct sunlight.
- Keep the packaging in a safe place for future reference. It contains important information.
- The product is intended only for use inside buildings.
- Only use the article under moderate climatic conditions (-20°C - 45°C, humidity below 95%).
- Do not use the product in areas in which electronic products are not permitted.
- Do not use the product in a damp environment and avoid splashing water.

Operation Warnings

Risk of electric shock

- Do not continue to operate the product if it is visibly damaged.

Care and maintenance

- Disconnect the device from the mains before cleaning and during prolonged periods of non-use.
- Only operate the product from a socket that has been approved for the device. Plug devices directly into the adapter and the product directly into the socket.
- To disconnect please remove all devices from the product before removing the product from the socket.

Verbatim Limited Warranty Terms

Verbatim warrants this product to be free from defects in material and workmanship for a period of 2 years from date of purchase.

This warranty excludes batteries.

If this product is found to be defective within the warranty period, it will be replaced at no cost to you.

You may return it with your original cash register receipt to the place of purchase or contact Verbatim.

Product replacement is your sole remedy under this warranty, and this warranty does not apply to normal wear or to damage resulting from abnormal use, misuse, abuse, neglect or accident, or to any incompatibility or poor performance due to the specific computer software or hardware used.

VERBATIM WILL NOT BE LIABLE FOR DATA LOSS OR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES, HOWEVER CAUSED, FOR BREACH OF WARRANTIES OR OTHERWISE.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state or country to country.

Note

Verbatim may at any time revise the content of this user guide without further notice.

Rights

Copyright © 2024 Verbatim. No part of this document may be reproduced in any form or by any means, for any purpose, without the express written permission of Verbatim.

All rights reserved.

All other brands and product names referenced herein are property of their respective owners.

WEEE Notice

The Directive on Waste Electrical and Electronic Equipment (WEEE), which entered into force as European law on 13th February 2003, resulted in a major change in the treatment of electrical equipment at end-of-life.

The WEEE logo (shown at the left) on the product or on its box indicates that this product must not be disposed of or dumped with your other household waste.

For more information about electronic and electrical waste equipment disposal, recovery, and collection points, please contact your local municipal household waste disposal service or shop from where you purchased the equipment.